

***ERJ 145***

**README FIRST**

**NOT FOR REAL WORLD USE!**


Our ERJ was built by many custom non standard commands, so please read this documentation before your flight.

### **Safety covered buttons and knobs:**

As you can see many of the buttons are covered and the buttons are unaccessible. You can right click on them to open them and then you can use the knobs and buttons underneath them.

### **Center Pedestal**

The GustLock is located on the center pedestal to provide lock of the elevator surfaces and the engine throttle levels on the ground. It can be locked and unlocked by clicking on the right marked area. You can also find the Takeoff Config button on the pedestal. By pushing it pilot can assure their plane is configured to a safe takeoff.



### **FMS keyboard mode**

The keyboard can operate the FMS in the following way:

Push Scroll Lock to engage FMS keyboard mode. From now you can directly type into the FMS. For the Line Select keys use the F1-F4 for the Left LSKs and F5-F8 for the right ones. Page Up and Page Down scrolls between the menus.